



### Download

SiecoSmart is available for both iOS and Android. Search the name "SiecoSmart" in App Store or Google Play.

### Download App



Android



iOS

### Add device

Log in the SiecoSmart, select "Add Device", and add the smart camera to the App according to the screen tips (please place the smart camera near the router when setting it up).



NOTE: If you need to re-select the WIFI network, please press and hold the "RESET" button for 5 seconds, the device will re-start, and the indicator will be flashing red

Design and specifications are subject to change without notice. Designed by Siera / Assembled in PRC. Product may vary in appearance and specifications.

Siera and Sieco are trademarks belonging to Siera Holding Group.

Warranty conditions according to [www.siecoelectronics.com/warranty](http://www.siecoelectronics.com/warranty)

[siecoelectronics.com](http://siecoelectronics.com)



### Functions

#### Video flip

Flip your video stream up or down for maximum flexibility.

#### Motion detection

Built-in motion sensors detect movement, and the camera will send you push notifications and app alerts.

#### Record

Support 24H continuous recording with high capacity SD storage or Cloud storage.

#### Day & Night

Never miss a moment, even in complete darkness, with powerful night-vision technology.



Day



Night



User Manual  
S34

## FAQ

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.

Q: How to cut the camera network to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why doesn't the device identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.


## Please consult this checklist for all parts.




Sieco S34




Power adapter



Pin




User Manual



Screws

## Description



Power port	DC 12V±10%
Status light	Solid red light on: The camera is turning on or malfunctional Blinking red light: Awaiting WiFi connection (slowly blinking) Connecting Wthe iFi (quickly blinking) Solid blue light on: The camera runs correctly
Microphone	Captures sound for your video
SD card slot	Support local SD Card storage (Max. 512Gb)
Speaker	Speak with the app and it will revert too
Reset	Press and hold for 5 seconds with pin to reset the camera (if you have modified settings, they will return to factory defaults)

## Install

**Mode 1.** Fix the camera to the wall with screws.

**Mode 2.** Adjust the camera angle to get a correct view (as shown in the image).

